



CN890S

NO	Code	Description	NO	Code	Description	NO	Code	Description
1	AA82411	SCREW M6X27	58	CN35059	CONTACT ARM GUIDE B	115	CN35642	HANGER
2	CN35328	EXHAUST COVER HOLDER	59	CN35002	ARM GUIDE	116	CN80525	GRIP ASSY
3	CN35294	EXHAUST COVER	60	KK23735	COMPRESSION SPRING 3735	117	CN35641	SPECIAL NUT
4	CN35296	EXHAUST FILTER B	61	KK23736	COMPRESSION SPRING 3736	118	BB40411	BOLT 6X20
5	CN35295	EXHAUST FILTER A	62	CN35004	CONTACT BUMPER	119	CN35644	CONTACT ARM C UNIT
6	BB40208	BOLT 6X28	63	CN35003	CONTACT ARM A	120	CN31323	TRIGGER VALVE HOUSING
7	CN35635	PROTECTOR	64	CN35327	BUMPER	121	CN33627	PILOT VALVE
8	CN35292	CYLINDER CAP UNIT	65	HH14729	O-RING AS568-144	122	KK24123	COMPRESSION SPRING 4123
9	CN35298	CYLINDER CAP SEAL	66	CN35312	NOSE	123	CN33723	TRIGGER VALVE STEM
10	CN35323	PLAIN WASHER	67	BB40221	SCREW M8X25	124	CN31346	TRIGGER VALVE CAP
11	KK23713	COMPRESSION SPRING 3713	68	EE39602	WASHER 7 CN65059 N10056FORMER EE39601	125	KK33247	SPRING 3247
12	HH14906	O-RING AS 568-133	69	CN35330	LATCH A	126	TA16138	S.T. LEVER
13	CN35839	HEAD VALVE PISTON	70	FF41258	PIN 1258	127	KK33144	TORSION SPRING 3144
14	HH19161	O-RING A 3.1X66.4	71	FF41599	PIN 1599 (REPLACES FF41587)	128	CN35648	TRIGGER
15	CN35307	HEAD VALVE SEAL	72	CN35315	DOOR	129	CN35139	CONTACT ARM GUIDE C
16	CN35334	PLAIN WASHER	73	KK33261	TORSION SPRING 3261 (REPLACES KK33169)	130	KK23725	COMPRESSION SPRING 3725
17	CN35302	PISTON STOP	74	CN33679	DOOR LUTCH	131	CN35140	CONTACT ARM A
18	CN35306	CYLINDER	75	CN31083	HOOK DUST COVER	133	KK23793	COMPRESSION SPRING 3793
19	HH12108	O-RING AG60(FORMER HH12114)	76	EE39609	RUBBER WASHER 1.8X6X2	134	KK23788	COMP. SPRING 3788
20	CN35325	CHECK VALVE	77	FF31520	STRAIGHT PIN 1520	135	CN35685	END CAP FILTER SA-10
21	CN35308	CYLINDER RING	78	FF31272	STRAIGHT PIN 1272	200	CN80546	TRIGGER VALVE KIT(CN890S)
22	HH12117	O-RING AG85	79	CN35007	ADJUST DIAL	201	CN80607	O-RING KIT FOR CN890S
23	HH19218	O-RING 4.5X48.7	80	CN35337	CONTACT ARM C			
24	CN35639	MAIN PISTON UNIT	81	HH11903	O-RING 1A 1.2 X 4 T29051 (REPLACES TA15277)			
25	CN35841	FRAME	82	KK23792	COMPRESSION SPRING 3792			
26	CN35636	WARNING LABEL(FRAME)	83	JJ10404	E-RING 3.2			
27	CN35075	TRIGGER LOCK LEVER	84	CN70048	CONTACT ARM B UNIT			
28	CN35331	END CAP SEAL	85	CN35339	CONTACT TIP			
29	TT05426	SWIVEL JOINT FMP3B	86	CN35899	SPACER			
30	BB40210	SCREW M5X20	87	CN35632	COVER			
31	CN35686	END CAP	88	CC00402	NUT M6			
32	BB40438	BOLT 6X32	89	CN35336	CHECK PAWL			
33	CN34309	PLASTIC SHEET LABEL (100421)	90	KK33221	TORSION SPRING 3221			
34	CN35634	LABEL CN890S (CE)	91	KK23710	COMP. SPRING 3710			
35	KK23507	SPRING 3507	92	HN10476	FEED PAWL			
36	CN35074	TRIGGER LOCK DIAL	93	FF42216	STEP PIN 2216			
37	FF21611	ROLL PIN 3X32 AW	94	HH11132	O-RING 1AP10A CN65072			
38	HH11105	O-RING AP7 N5525	95	CN35314	FEED PISTON			
39	HH11125	O-RING AP12 CN65086	96	HH11143	O-RING AP21 851437			
40	HH11138	O-RING AP20	97	KK23737	COMPRESSION SPRING 3737			
41	CN33909	TRIGGER VALVE HOUSING	98	KK23225	SPRING 3225			
42	FF30161	PIN 161	99	CN31570	FEED PISTON STOP			
43	HH11119	O-RING AP6 N10027	100	CN31571	SPRING COLLAR			
44	HH11209	O-RING 1BP7 N10028	101	JJ22407	C-RING 26			
45	CN35655	PILOT VALVE	102	CN35651	MAGAZINE COVER			
46	HH11113	O-RING AP9 N5528	103	CN34879	WARNING LABEL			
47	CN31436	PILOT ORIFICE	104	CN31963	POST CAP			
48	KK23129	COMPRESSION SPRING 3129	105	CN35317	MAGAZINE			
49	CN35128	TRIGGER VALVE STEM	106	CN35318	NAIL SUPPORT			
50	HH11901	O-RING 1.4 X 2.5 CN65020	107	CN35340	MAGAZINE WEAR CLIP			
51	CN33910	TRIGGER VALVE CAP	108	CN30601	SPACER CN65091			
52	CN35115	CONTACT LEVER	109	KK13144	SPRING 3144 (SUPERCEDES KK13040)			
53	CN35001	TRIGGER	110	CN30602	SPRING HOOK			
54	FF22402	SPRING PIN 3X16 (LIGHT LOAD)	111	FF41287	PIN 1287			
55	KK23282	COM. SPRING 3282	112	CN35322	DUST COVER			
56	CN35656	LEVER	113	BB40211	BOLT 6X35			
57	CN34500	SPRING LEVER	114	EE33111	PLAIN WASHER 6			