


N401C-1

COIL-FED PNEUMATIC NAILER
CLAVADORA NEUMÁTICA ALIMENTADA POR ROLLO
CLOUEUR PNEUMATIQUE À ENROULEMENT



IP1223-1REVC 11/08
 TO BE USED WITH PARTS LIST IP1223-2 AND OPERATION AND MAINTENANCE MANUAL 171119.

See reverse side for available
 accessories (not included)

BOSTITCH

	N401C-1		Parts List: IP1223-2REVD		
To be Used with tool parts illustration:			IP1223-1REVB		
and operation and maintenance manual:			171119		
Serial Number on the Tool:			N401C-1		7 346 000 and Higher
ITEM	PART #	DESCRIPTION	ITEM	PART #	DESCRIPTION
101	MSC6100-35	SCREW, SHCS, M6X1.00X35 LG.	401	2041104-08020	O-RING
			402	11383-1030001	MUZZLE PROTECTOR
			404	MSC10150-30	SCREW, SHCS M10X1.50X30 LG.
105	11397-1034702	GUIDE, COVER	405	2041100-01091	O-RING
106	11302-1034701	CYLINDER CAP SEAL	406	N80128	PISTON, FEED
107	11370-1030001	SEAL	407	851384	O-RING, .987 X .103
108	11360-1030001	COMPRESSION SPRING	408	N80123	BUMPER, FEED PISTON
109	2041108-06050	O-RING	409	2040100-04080	BOLT ASSY
110	11381-1030001	WASHER	410	N80122	SPRING, COMPRESSION
111	11368-1030001	HD VALVE PISTON	411	N80124	COVER, FEED PISTON
112	2041108-07050	O-RING	412	2040300-08010	C- RING
113	2041100-06011	O-RING	413	1134B-0864701	DUST SHIELD PLUG
114	11204-1030002	ASSEMBLY, PISTON/DRIVER	414	11310-0254702	DOOR LATCH
115	11399-1030001	COLLAR	415	11311-1030001	LATCH SPRING
116	11320-1030002	CYLINDER	416	11361-1034701	DOOR
117	11321-1030001	CYLINDER SPACER	417	854004	WASHER, RUBBER-7
118	2041104-11010	O-RING	418	1131K-1034701	PIN
119	2041108-07060	O-RING	419	854011	SPRING-3109, COMPRESSION
120	11327-1034702	BUMPER-A	420	N70149	PAWL, CHECK
121	MSC5080-12	SCREW, SHCS, M5X0.8X12 LG.	421	11359-1034701	PIN-NAIL STOP
122	11371-1034701	DEFLECTOR	422	11362-1034701	DOOR SHAFT PIN
123	1132T-1030001	MUFFLER	423	11330-1034701	SAFETY
124	11327-1034703	BUMPER-B	424	11337-1030001	SAFETY SPRING
125	1135R-1034701	PROTECTIVE CUSHION	425	N70145	GUIDE ARM
214	2041100-01050	O-RING	426	11354-1034701	PLATFORM, CANISTER
215	2040400-05150	SPRING PIN	427	11357-1034701	MAGAZINE POST
			428	1138Y-0954701	RUBBER RING
			429	1134M-0864701	SPRING BASE
			430	11356-1030001	TRAY,METAL
219	102549	PIN,SPECIAL SPIRAL	431	1138W-0860001	SPACER
220	2040404-05130	SPRING PIN	432	11328-0970001	PULL SPRING
221	TVA6	KIT, TRIGGER VALVE	433	11355-1034701	CANISTER COVER
222	N50082A	ASSEMBLY, TRIGGER	434	11365-0864701	PIN FEED PISTON
			435	11306-1034702	FEED FINGER
301	11230-1038001	FRAME	436	N80121	ROD, FEED PISTON
302	MRG049431	O-RING	437	N80120	SPRING, TORSION
303	N70167	END CAP	438	MSC6100-40	SCREW, SOC. HD. CAP M6X1.00X40 LG
			439	1134R-1034701	SPRING COVER
			440	2040501-04010	BOLT CAP
			441	1136R-1034701	MAGAZINE SHAFT PIN
			442	2040202-04010	FLAT WASHER
			443	1134N-1014701	SPRING BASE A
			444	1131D-0460001	URETHANE RETAINER
			445	1035U-1010001	PROTECTOR WASHER
			446	103559	BUSHING, WEAR
			447	1139G-1034701	SECOND HANDLE BASE
			448	1137K-1030001	HANDLE
			449	7BUSB-3103003	ASSEMBLY, CANISTER
			450	7BUSB-3103001	ASSEMBLY, CAP
			451	7BUSB-3103002	ASSEMBLY, NOSE