



| NO | Code | Description | NO | Code | Description |
|----|---------|---|-----|---------|--|
| 1 | AA82427 | Screw 8 X 20 (Hexagonal Hall)(Replaces BB49813+CN3 | 56 | CN34420 | CONTACT ARM COVER B |
| 2 | CN32631 | Exhaust Cover Holder For Use W/AA82427(REP.CN32582) | 57 | KK23256 | COMPRESSION SPRING 3256 |
| 3 | HH11132 | O-RING 1AP10A CN65072 | 58 | CN35821 | CONTACT ARM UNIT |
| 4 | CN32243 | EXHAUST COVER(FORMER CN31933) | 59 | HH19198 | O-RING 1A 1.9 X 47 |
| 5 | CN31934 | EXHAUST FILTER | 60 | HH19125 | O-RING A1.6X4.2 CN65064 |
| 6 | CN32242 | EXHAUST COVER SEAL | 61 | CN34419 | NOSE(REPLACES CN31874) |
| 7 | BB40428 | SCREW 6MM X 25MM | 62 | BB40413 | SOC.HD.CAP SCREW 6X22 N5530 |
| 8 | CN35767 | PROTECTOR | 63 | EE39602 | Washer 7 CN65059 N10056Former EE39601 |
| 9 | CN34402 | CYLINDER CAP UNIT | 64 | FF41501 | STEP PIN 1501 |
| 10 | CN34416 | CYLINDER CAP SEAL | 65 | CN31083 | HOOK, DUST COVER |
| 11 | CN31937 | SPACER | 66 | CN31882 | DUST SHIELD |
| 12 | CN33008 | PISTON STOP(FORMER CN31936) | 67 | CN30587 | DOOR LATCH CN65053 |
| 13 | KK23578 | COM. SPRING 3578 | 68 | KK23123 | SPRING 3123 CN65054 |
| 14 | CN33610 | HEAD VALVE WASHER | 69 | KK23109 | SPRING 3109 CN65057 |
| 15 | HH11156 | O-RING ARP568-137 | 70 | CN31881 | CHECK PAWL |
| 16 | HH11909 | O-RING 2.6X41.5 | 71 | CN31880 | DOOR <<<<< |
| 17 | CN34405 | HEAD VALVE PISTON(FORMER CN31935) | 72 | FF21234 | W.S. PIN 3 X 12 CN65055 |
| 18 | CN33745 | CYLINDER SEAL | 73 | FF41502 | STEP PIN 1502 |
| 19 | CN31866 | MAIN PISTON UNIT <<<<< | 74 | KK33058 | SPRING 3058 |
| 20 | HH11101 | O-RING 1AP38 | 75 | CN31875 | FEED PAWL (9.5MM)(FORMER CN31884) |
| 21 | CN31864 | CYLINDER SLEEVE | 76 | FF41263 | PIN 1263 |
| 22 | HH11157 | O-RING ARP568-136 850006 | 77 | HH19197 | O-RING 1A 2.4 X 9.8 |
| 23 | CN31865 | CHECK VALVE | 78 | CN31876 | FEED PISTON |
| 24 | CN31429 | CYLINDER RING <<<<< | 79 | HH11143 | O-RING AP21 851437 |
| 25 | HH12106 | O-RING 1AG75 | 80 | KK23257 | COMPRESSION SPRING 3257 |
| 26 | CN31890 | BUMPER (FOR N55 ONLY)(FORMER CN31432) | 81 | KK23258 | COMPRESSION SPRING 3258 |
| 27 | CN34401 | FRAME | 82 | CN31878 | SPRING GUIDE |
| 28 | CN34404 | LABEL(CN55) | 83 | CN31877 | FEED PISTON BUMPER |
| 29 | CN34726 | WARNING LABEL | 84 | CN31879 | SPRING COLLAR |
| 30 | CN34703 | GRIP COVER | 85 | JJ22407 | C-RING 26 |
| 32 | FF21254 | PIN 3 X 28 N10038 | 86 | CN35822 | MAGAZINE CAP 89 CN31963 Post Cap |
| 33 | HH12118 | O RING 1AG35 | 90 | CN35823 | NAIL SUPPORT |
| 34 | CN34403 | END CAP | 91 | CN30601 | SPACER CN65091 |
| 35 | BB40457 | BOLT 6X38 FOR CC00402)(REPLACES BB40469) | 92 | KK13144 | SPRING 3144 (SUPERCEDES KK13040) |
| 36 | EE39138 | WASHER 138 | 93 | CN34407 | MAGAZINE POST |
| 38 | HH11159 | O-RING ARP568-016 86459 | 94 | CN30602 | SPRING HOOK |
| 39 | CN31885 | SPACER | 95 | CN34406 | MAGAZINE |
| 40 | HH11151 | O-RING ARP568-013 N10067 | 96 | EE39603 | RUBBER WASHER 14(REPLACES EE39606) |
| 41 | CN32247 | TRIGGER VALVE HOUSING(REPLACES CN/KN10387) | 97 | FF31251 | PIN 1251 |
| 42 | HH11138 | O-RING AP20 | 98 | CC00402 | NUT M6 |
| 43 | HH11119 | O-RING AP6 N10027 | 99 | CN31872 | ARM COVER A |
| 44 | CN31589 | PILOT VALVE | 100 | CN30707 | COLLAR |
| 45 | HH11209 | O-RING 1BP7 N10028 | 101 | CN31715 | TRIGGER VALVE STEM CN-670DS |
| 46 | HH11113 | O-RING AP9 N5528 | 102 | CN31716 | TRIGGER VALVE CAP CN-670DS |
| 47 | KK23129 | COMPRESSION SPRING 3129 | 103 | KK23228 | SPRING 3228 |
| 48 | CN31347 | TRIGGER VALVE STEM | 104 | CN34300 | CONTACT LEVER DS |
| 49 | HH11901 | O-RING 1.4 X 2.5 CN65020 | 105 | CN30276 | TRIGGER (S.T.) |
| 50 | CN31346 | TRIGGER VALVE CAP | 106 | CN34728 | HANGER |
| 51 | FF30161 | PIN 161 | 107 | BB40422 | BOLT 6X30 FOR CC00402)(REPLACES BB40438+CC49408) |
| 52 | TA10506 | CONTACT LEVER | 108 | CN33627 | PILOT VALVE |
| 53 | TA10505 | TRIGGER | 109 | CN80610 | O-RING KIT FOR CN55 |
| 54 | FF21220 | PIN 3X16 N10098 | 110 | CN80548 | TRIGGER VALVE KIT(SN90A) |
| 55 | CN31870 | ARM GUIDE | | | |